FRS FREQUENCY LIST*

Channel 1: 462.5626	Channel 8:	467.5675
Channel 2: 462.5875	Channel 9:	467.5875
Channel 3: 462.6125	Channel 10:	467.6125
Channel 4: 462.6375	Channel 11:	467.6375
Channel 5: 462.6625	Channel 12:	467.6625
Channel 6: 462.6875	Channel 13:	467.6875
Channel 7: 462.7125	Channel 14:	467.7125
1) EDC Dedition and 27 DL tangent	General 11 and 44 and	ist to a s??

1) FRS Radios use 37 PL tones, often called "quiet tones"

Bandplan GMRS Radio Service

There are 23 GMRS channels. None of the GMRS channels are assigned for the exclusive use of any system. License applicants and licensees must cooperate in the selection and use of the channels in order to make the most effective use of them and to reduce the possibility of interference.

Channel Allocation		
Station Type	Frequency (MHz)	
mobile station or small base station operating in the		
simplex mode*	462.5625**	
	462.5875**	
	462.6125**	
	462.6375**	
	462.6625**	
	462.6875**	
	462.7125**	